


BL17&BL17SP エンジン分解図

1T65NT Part Illustrations



BL17&BL17SP エンジンパーツリスト -1

Ref.	Part Number	Description	Ref.	Part Number	Description
1	100011463-0002	Nut, M6	43	100009234	Ignition Module
2	100007221-0001	Recoil Starter	44	100008771	Fuel Cap
3	100007459	Starter Handle	45	100008872	Fuel Cap Chain
4	100007575	Starter Handle Insert	46	100008880	Lock Nut
5	100007511-0001	Starter Cover	47	100008939	Damping Pad
6	100007438	Recoil Spring	48	100009024	Fuel Tank Shield
7	100007417	Starter Reel	49	100008691	Fuel Tank
8	100007471	Starter Rope	50	100009020	Fuel Filter
9	100007448	Return Spring	51	100005136	Clamp
10	100007427	Starter Pawl	52	100017711	Fuel Hose, φ6.3×φ12.5×110
11	100007678	Central Shaft	53	100007919	Idle Spring
12	100007433	Guide Plate	54	100007946	Throttle Linkage
13	100007483	Spring	55	100008459	Governor Shield
14	100007568	Alignment Bolt	56	100008411	Governor Lever
15	100010306	Stud, M6×75	57	100007998	Governor Lever
16	100010307	Stud, M6×73	58	100010338-0003	Bolt
17	100007605	Blower Housing	59	100011463-0002	Nut, M6
18	100007608	Blower Housing	60	100007833	Governor Spring
19	100004215	Bush, φ16×12-φ10×φ6.5	61	100008097	Governor Gear Bracket Assembly
20	100011462-0001	Nut, M14×1.5	62	100007986	Cotter Pin
21	100009499	Flywheel	63	100017630	Oil Seal, φ6×φ11×4
22	100017639	Oil Seal, φ20×φ42×7	64	100007973	Governor Gear Shaft
23	100011260-0005	Bolt, M6×10	65	100002621	Crankcase
24	100007139	Shield Block	66	100010144	Gasket, Crankcase
25	100011262-0003	Bolt, M6×14	67	100003576	Crankshaft
26	100011268-0003	Bolt, M6×25	68	100010577	Woodruff Key
27	100009613	Brake Assembly	69	100003467	Drive Timing Gear
28	100011451-0003	Nut, M5	70	100004111-0001	Dipstick
29	100009665	Brake Pin	71	100004148	O-Ring, Dipstick
30	100009681	Nylon Washer	72	100004187	Dipstick
31	100009640	Brake Block	73	100010527-0001	Washer, φ25.4×1×φ34
32	100009630	Brake Bracket	74	100008451	Governor Gear Mounting Plate
33	100009647	Brake Spring	75	100008289	Governor Gear
34	100011417-0001	Nut, M3	76	100008322	Governor Cup
35	100009670	Insulator Board	77	100031642	Washer, φ6.2×0.6×φ15
36	100010942-0001	Screw, M3×12	78	100008328	Retaining Ring
37	100009655	Ground Contact	79	100008311	Governor Shaft
38	100009668	Brake	80	100008365	Governor Gear
39	100004052	Breather Cover	81	100008334	Governor Fly Weight
40	100010259	Gasket, Oil Filter	82	100008345	Governor Shaft
41	100008440	One-way Valve Spring	83	100008353	Governor Gear
42	100004085	Breather Valve	84	100010435	Washer, φ6.2×0.6×φ12

BL17&BL17SP エンジンパーツリスト -2

Ref.	Part Number	Description	Ref.	Part Number	Description
85	100010544	Pin, $\phi 7 \times 14$	130	100010558	Pin, $\phi 10 \times 16$
86	100010554	Pin, $\phi 9 \times 14$	131	100004391	Push Rod
87	100011269-0003	Bolt, M6 \times 28	132	100004261	Tappet
88	100010459	Washer, $\phi 10 \times 1.5 \times \phi 16$	133	100004281	Camshaft
89	100010272	Earth Bolt	134	100003235	Piston Ring Set
90	100002949	Crankcase Cover	135	100003142	Piston Ring, 1st
91	100017617	Oil Seal, $\phi 25 \times \phi 38 \times 7$	136	100003184	Piston Ring, 2nd
92	100004661	Air Filter Assembly	137	100003352	Scraper Ring, Oil Ring
93	100005670	Primer	138	100003311	Lining Ring, Oil Ring
94	100005673	Primer Base	139	100003220	Circlip
95	100005677	Primer Cup	140	100003067	Piston
96	100004836	Air Filter Cover	141	100003118	Piston Pin
97	100004764	Air Filter Element	142	100003441	Connecting Rod Assembly
98	100004989	Air Filter Base	143	100003392	Connecting Rod
99	100002828	Breather Hose	144	100003417	Connecting Rod Cap
100	100017758	Fuel Hose, $\phi 3.2 \times \phi 6.5 \times 80$	145	100003431	Connecting Rod Bolt
101	100005946	Gasket, Air Filter	103	100005920	Gasket, Carburetor
102	100005245	Carburetor	104	100005598	Insulator
a	100005688	Idle Jet	105	100005553	Gasket, Carburetor Insulator
b	100000018	Primer Line	106	100010350	Stud, M6 \times 98
c	100005989	Carburetor Body	107	100002370	Cylinder Head
d	100005895	Float Pin	108	100002461-0001	Bolt, M8 \times 54_10.9
e	100005888	Needle Valve	109	100009383	Spark Plug
f	100006053	Needle Valve Spring	110	100004520	Intake Valve
g	100005700	Float	111	100004599	Intake Valve Seal
h	100005717	O-Ring, Float Bowl	112	100004543	Exhaust Valve
i	100005705	Float Bowl	113	100004564	Valve Spring
j	100006037	O-Ring, Float Bowl	114	100004579	Valve Spring Seat
k	100005725	Bolt	115	100004468	Rocker Arm Base
l	100006029	Drain Bolt	116	100004421	Rocker Arm Assembly
m	100006033	Gasket, Drain Bolt	117	100004492	Stud
n	100005744	Main Jet	118	100004438	Rocker Arm
o	100005861	Nozzle Tube	119	100004457	Adjust Nut
p	100005723	Idle Adjusting Screw	120	100004488	Lock Nut
q	100005543	Gasket	121	100010174	Gasket, Valve Cover
r	100010983-0002	Screw, M3 \times 6	122	100002308	Valve Cover
s	100010883-0002	Washer, $\phi 3$	123	100010349	Stud, M6 \times 76
t	100005807	Throttle Plate	124	100006523	Gasket, Muffler
u	100006057	Throttle Shaft	125	100006280	Muffler
127	100006596	Spark Arrester	126	100006827	Muffler Guard
128	100010996-0001	Self-tappling Screw, ST3.5 \times 9.5			
129	100010202	Gasket, Cylinder Head			