


Model LS 8 ROVER



MTD ROVER LS8 パーツリスト

Ref.	Part Number	Description
1	656-04037	Pulley .50 ID x 2.38 OD
2	681-04065A	Frame Assembly
3	710-0191	Hex Screw 3/8-24 x 1.25
4	710-0653	Hex Washer Screw, 1/4-20 x .375
5	710-0654A	Hex Washer Screw, 3/8-16 x .88
6	710-1650	Self-tapping Screw, 5/16-18 x .875
7	710-3005	Hex Bolt 3/8-16 x 1.25
8	712-04065	Flange Lock-Nut 3/8-16, Nylon
9	732-04217	Extension Spring .375 x 2.95
10	936-0452	Belleville Washer
11	748-04125	Shoulder Spacer .30 x .46
12	754-04128	Belt, V-Type, 3L, 33.92" Lg.
13	756-04133	Pulley, V-idler, 2 x 2.75 x .625-3L
14	756-04304	Idler Pulley
15	781-04132	Belt Idler Bracket
16	781-04161	Belt Cover
17	629-04161	Harness, Interlock
18	681-04064	Tank Assembly
19	738-04237A	Shoulder Screw #10-16 x .50
20	711-06452	Pin, locking
21	725-04363	Switch, Interlock
22	726-3046	Foot Pad Clips (Not Shown)
23	732-04085	Extension Spring .480 OD x 5.0
24	736-04178A	Washer, slotted, felt
25	737-04148	Drain Plug
26	738-0930	Shoulder Bolt
27	781-04168	Bracket, Lock, Cylinder
28	918-04241	Cylinder
29	710-0623	Hex Tap Screw, 3/8-16 x .62
30	711-04585	Clevis Pin
31	913-04036	Link, Handle, Valve

Ref.	Part Number	Description
32	914-0104	Cotter Pin
33	720-04088	Grip
34	727-04182	Hose, Valve, Cylinder
35	737-04155	Adapter, Hydraulic
36	737-04154	Adapter, Hydraulic
37	747-04539	Control, Valve, Hydraulic
38	747-04707	Handle, Rod
39	681-04087B	Assembly Bracket, Push
40	710-0615A	Hex Cap Screw, 3/8-16 x 5.0
41	710-0382	Hex Cap Screw, 1/2-13 x 5.00
42	726-0299	Push Cap x 1/2" Rod
43	750-0802	Spacer .640
44	710-3008	Hex Cap Screw, 5/16-18 x .75
45	710-3008	Hex Cap Screw, 5/16 x 1.00
46	712-3004A	Flange Locknut 5/16-18, Nylon
47	918-04243	Pump, gear
48	726-04079	Hose Clamp
49	727-04154	Hose
50	727-04156	Hose, return
51	727-04157	Hose, Inlet
52	737-04187	Fitting, elbow
53	711-04575	Axle
54	734-1781	Wheel Assembly 8 x 1.75 Grey
55	710-0604A	Hex Washer Screw, 5/16-18 x .75
56	781-04124	Bracket, Support
57	918-0481A	Valve
58	737-0192	90 Degree Solid Male Adaptor
59	914-0122	Square Key 3/16 X 3/4
60	712-3004A	Nut, 5/16-18, Flangelock
61	781-05004	Cylinder Support Bracket
62	712-3022	Nut, 1/2-13, Hexlock
63	736-04655	Flat Washer: 3/16 x 3/4 x 16G
64	710-05483	Screw: 3/16 x 1/2
65	741-04555	BRG:SLV:.638x.753.615
66	750-04668	Spacer:.385x.625x4.070